



# For Brighter Bathrooms, Add PVC Shiplap.

## The farmhouse feel: bring it in

Beyond historic homes and barns, shiplap has been working its fresh, timeless charms on home interiors as well. While white shiplap is the most common and familiar form, rustic wood and paintable PVC styles make this material versatile enough to use anywhere in your home.

Royal® prefinished PVC Shiplap makes a particularly compelling addition to bathrooms, creating a clean, comfortable space while demanding relatively little in time and sweat. It's waterproof, mold resistant, flexible and works well in a space with lots of slants and angles. Plus, it's inexpensive, lightweight and easy to install.

Get ready to create a clean slate in your bathroom by following a few simple steps.

### ALL THE MATERIALS YOU'LL NEED:

- Royal PVC Shiplap
- 1" x 6" board for baseboard
- Royal Corner Guards
- Royal 2.5' x 8' Prefinished PVC Chair Rail Moulding
- Construction adhesive
- Caulk
- Caulking gun
- Nail gun and brad nails (if shiplap extends beyond tile)
- Spackle



## Step 1

If you're installing over tile, prep your walls by wiping them down to ensure they're free of debris and dust. If you're extending shiplap beyond the lower tile wall, nail shim pieces to ensure shiplap at the top of the wall is flush with the bottom of the wall.

---

## Step 2

Cut your shiplap to size and squeeze a few beads of construction adhesive along the edges and middle of the shiplap plank.

---

## Step 3

Firmly adhere the shiplap to the tile, and if applicable, shoot a few nails into the shiplap at the top of the wall to further secure it. Work your way around the room. Finish outside corners with PVC corner guards.

---

## Step 4

Trim it out by adding a 1" x 6" baseboard to the bottom of the shiplap using construction adhesive. Install chair rail to the top of the planks using brad nails.

---

## Step 5

Caulk any gaps for a smooth finish. Paint in your favorite latex color.